



# **VioGate-340**

## **IP Surveillance Server**

### **User Manual**

**Version 1.0.0**



©Copyright 2006. QNAP Systems, Inc. All Rights Reserved.  
January 9, 2006

## **TRADEMARKS**

QNAP® and VioGate™ are registered trademarks of QNAP Systems, Inc. Microsoft®, Windows® and Internet Explorer® are registered trademarks of Microsoft Inc. All other brand or product names are trademarks of their respective companies or organizations.

## **WARRANTY**

QNAP guarantees all VioGate-340 IP surveillance servers have passed strict and complete test and can operate normally in general condition. In case of system malfunction within the warranty period under normal operation of this product, QNAP will provide product maintenance service.

## **NOTICE**

This product can only operate indoor. Please do NOT place the product outdoor or put any objects on the product.

## Table of Contents

<b>1. Overview of VioGate.....</b>	<b>5</b>
1.1 About VioGate.....	5
1.2 Features.....	5
1.3 New Functions.....	6
1.4 System Requirements .....	7
1.5 Package Contents .....	8
1.6 System Overview.....	8
<b>2. Install VioGate .....</b>	<b>9</b>
<b>3. VioGate CD-ROM.....</b>	<b>16</b>
<b>4. Using VioGate.....</b>	<b>18</b>
4.1 Accessing Administration Page.....	18
4.2 System Configuration .....	26
4.3 System Settings .....	28
4.4 Network Settings.....	29
4.5 IP Security .....	31
4.6 User Management.....	32
4.7 Camera Settings.....	34
4.8 Recording Settings.....	39
4.9 Event Handling.....	44
4.10 Event Action Settings .....	50
4.11 Statistics and Logs.....	57
4.12 System Tools .....	58
<b>5. Using VioGate Player/ Finder/ Master Lite.....</b>	<b>61</b>
5.1 Using VioGate Player.....	61
5.2 Using VioGate Finder.....	62
5.3 Using VioGate Master Lite .....	65
<b>6. Maintenance.....</b>	<b>68</b>
6.1 Restart/ Shut down VioGate .....	68
6.2 Reset Administrator Password & Network Settings .....	69
6.3 System Update.....	71
6.4 Restore to Factory Default.....	71
<b>Appendix A Terms and Glossary .....</b>	<b>72</b>
<b>Appendix B Dynamic Domain Name Registration.....</b>	<b>74</b>
<b>Appendix C Connecting VioGate via PC.....</b>	<b>78</b>

<b>Appendix D</b>	<b>Connecting VioGate via RS-422/ 485 Port .....</b>	<b>81</b>
<b>Appendix E</b>	<b>PTZ Control Information .....</b>	<b>85</b>
<b>Appendix F</b>	<b>VioGate Finder .....</b>	<b>86</b>
<b>Appendix G</b>	<b>Using VioGate with IP Sharing Router .....</b>	<b>88</b>
<b>Appendix H</b>	<b>GPIO Connections.....</b>	<b>89</b>

# 1. Overview of VioGate

**Note:** Unless otherwise specified, VioGate mentioned herein refers to VioGate-340 IP Surveillance Server.

## 1.1 About VioGate

VioGate-340 adopts advanced MPEG-4 image compression technology and hardware compression chipset to minimize image and maintain DVD (720x480) quality resolution for instant display. VioGate-340 is both a network image server and a network video monitoring module. The management software VioGate Master supports monitoring and managing various VioGate products over the network at the same time. VioGate-340 can also partner with QNAP NAS (network attached storage) server for backup and storage of remote video recording.

## 1.2 Features

- 4-channel Full-D1 (720x480) instant MPEG-4 hardware compression
- SMART recording mode for automatic adjustment recording speed
- Supports 2 x 3.5" hard disks to preserve recording data for longer period
- Built-in Gigabit network chipset for high speed data transfer
- Multiple event alert triggering mode, e.g. motion detection triggering email or SMS notification
- Support multiple high speed dome cameras and control modes

## **1.3 New Functions**

### **1.3.1 SMART Recording**

VioGate-340 supports SMART Recording technology. When the monitoring screen stays the same for 5 minutes, VioGate will adjust the bit rate and frame rate for recording automatically. When moving object is detected in the monitoring screen, the system will automatically resume the bit rate and frame rate to original settings. For more information, please refer to Chapter 4.8.

### **1.3.2 Backup storage path**

VioGate-340 provides two storage paths for saving recording and snapshot files. You can select to save recording and snapshot files on local disk, NAS, remote PC or an FTP site. The second storage acts a backup storage path. When the primary storage path fails, currently recording files can be automatically switch to the second storage within the time period specified by user to enhance continuous and steady data storage. For more information, please refer to Chapter 4.8.

### **1.3.3 Dual hard disk function**

VioGate-340 supports two IDE hard disks at maximum and provides linear disk volume to maximize storage capacity and increase the time for reserving recording and snapshot files. For more information, please refer to Chapter 4.12.

### **1.3.4 PTZ camera**


VioGate-340 supports pan/tilt/zoom cameras which are video cameras with enhanced control mechanism. You can select one-click operation or press button for continuous actions, and increase adjustable camera rotation angles in **Camera Settings** page. For more information, please refer to Chapter 4.7.

## 1.4 System Requirements

- Analog B/W or color camera (NTSC or PAL)
- Network requirements:  
RJ-45 Ethernet connection and dynamic or static IP address
- Client side PC requirements:  
Pentium 4 or above CPU  
256MB system memory or above  
VGA card (recommended resolution: 1024x768 pixels)  
Microsoft Windows 2000/ XP  
Internet Explorer 5.5 or above




**Note:** To connect VioGate by IE browser, "Security level for this zone" in Internet Options must be set to Medium or lower.



## 1.5 Package Contents

- 4-channel MPEG IP surveillance server VioGate-340
- Power cord
- Network cable
- CD-ROM (user manual and software inclusive)
- GPIO connector
- Quick Installation Guide

## 1.6 System Overview






## 2. Install VioGate

Please follow the steps below to install VioGate. If you are not familiar with network settings, consult your Internet service provider (ISP) or network administrator for the details.

- **Connecting the server to local network with DHCP server**



- Connect VioGate to the local network with the enclosed CAT-5 Ethernet cable.
- Connect camera to video input connectors of VioGate via video cable. Up to 4 cameras can be supported.
- Connect the power cord to VioGate and turn on the server.

- iv. Insert VioGate CD-ROM in your PC and click VioGate Series.




- v. Run VioGate Finder.







- viii. Select "**Use Fixed IP Address**" and enter the TCP/IP settings.



The image shows a "VIOCARD-300 Configuration" dialog box. It has two main sections: "System" and "TCP/IP".

**System Section:**

- Name:** A text field containing "Daniel\_DVR020EF02A".
- Date (mm/dd/yyyy):** Three separate text fields containing "02", "15", and "2005", separated by slashes.
- Time (hh:mm:ss):** Three separate text fields containing "17", "09", and "48", separated by colons.



**TCP/IP Section:**


- Obtain the IP address automatically (DHCP):** A radio button that is not selected.
- Use Fixed IP Address:** A radio button that is selected.
- IP Address:** A text field containing "192 . 168 . 0 . 1".
- Subnet Mask:** A text field containing "255 . 255 . 255 . 0".
- Gateway:** A text field containing "192 . 168 . 0 . 1".

At the bottom of the dialog box are two buttons: "OK" and "Cancel".

- ix. Click **OK** and restart the server.
- x. Launch the web browser and enter the IP address of VioGate. Login VioGate.

- **Connecting VioGate to the Internet using ADSL service**

- If VioGate is connected to the Internet through ADSL (i.e. dynamic IP is used), it is recommended to use Dynamic DNS service to connect VioGate with an easy-to-remember server name. Register an account name on <http://www.dyndns.org>, <http://update.ods.org>, or <http://www.dhs.org>, to obtain a user name, password and a domain name. (For further details, please refer to Appendix B).
- Please refer to Appendix C for details of connecting VioGate to PC.
- Click on the setting icon  on the left of the screen. In the setup page, choose  "Network Settings" and select "Use broadband connection to the Internet (PPPoE)". Then enter the correct user name and password to connect to the ADSL.
- Check the box "Enable Dynamic DNS Service". Enter the user name, password, and host name. Select "Dynamic IP address".



- v. Click **Save** and wait for a few seconds for VioGate to apply the new network configuration.
- vi. Shut down the VioGate, and connect the server to the ADSL modem.
- vii. Restore the network settings of your PC and restart VioGate.
- viii. Enter the host name you have registered in the web browser. When you have completed the settings for VioGate successfully, you can access the server administration page.

### **Default Network Configuration of VioGate**

By default, VioGate will acquire IP address and other TCP/IP network protocol settings from DHCP server. If DHCP server is not supported on the network, VioGate will use the following default settings:

IP Address: <b>192.168.0.1</b>
Subnet Mask: <b>255.255.255.0</b>

Login the server with the default administrator account:

User name: <b>administrator</b>
Password: <b>admin</b>

### 3. VioGate CD-ROM

QNAP provides different software for various surveillance products. When using VioGate-340, you will need to install VioGate Finder, VioGate Player, and VioGate Master Lite. To use these programs, click **VioCard-300**.





You may select to install three programs dedicated for more convenient use of VioGate-340. After installing the programs, you can find the shortcuts on the desktop of your PC. Run these shortcuts to use the programs.

Field	Description
VioGate Finder	To find all available VioGate servers on the same network
VioGate Player	To view recorded data of all cameras
VioGate Master Lite	To monitor multiple VioGate servers available on the same network



## 4. Using VioGate

When you have installed VioGate successfully, you can use the web browser to connect and manage VioGate. VioGate supports Microsoft Internet Explorer 6.0 or above.

### 4.1 Accessing Administration Page


You can access VioGate administration page by one of the following methods:


- Enter the IP address of VioGate in the web browser. You can find the IP address by VioGate Finder.
- Run VioGate Finder, and double click on the server you want to configure on the list.
  - i. The first time you access administration page, download ActiveX control.
  - ii. When the following login window appears, select a language for web display. Enter the user name and password of the administrator.

Default user name: **administrator**

Password: **admin**







The image shows the VioGate login window. At the top, there is a logo consisting of a stylized eye icon followed by the text "VioGate". Below the logo, there is a central panel with a wood-grain background. Inside this panel, the "Server Location" is set to "172.17.22.34". The "User Name" field contains "administrator". The "Password" field contains "\*\*\*\*\*". Below the password field, there is a checkbox labeled "Save password" which is currently unchecked. At the bottom of the window, there is a language dropdown menu set to "English", and two buttons labeled "OK" and "Cancel".


- iii. Upon successful login to the server, click  on the left column of the monitoring page to enter system configuration page.




### 4.1.1 Display Mode

You can select the desired display mode for the monitoring page.


Button	Description
	View Single Camera
	Adjust Window Size
	Full-Screen Mode
	Picture-in-Picture Mode
	Quad Mode
	Sequential Mode

Login VioGate as an administrator, you can click the button  to access system administration page to view and modify all settings.

### 4.1.2 Manual Recording Video


Click  to record the selected camera's live video to local PC. Click the button again to stop recording. The recorded files will be saved as vg3 format. You can play the files with VioGate Player in the CD-ROM.


### 4.1.3 Manual Snapshot Taking

Click  to save a still image file to the computer.

#### 4.1.4 System Warnings

When events set in Event Handling section (refer to Chapter 4.9) are triggered,

the monitoring page will show an event notification icon  to inform the administrator on the current status of the server. Double click the warning icon to view the detailed description.




Event notification will be shown in the following conditions:

- Motion is detected
- Video input is lost
- Connection to storage device fails
- Storage space is full
- Alarm input is triggered






#### 4.1.5 Playback Video Files

To playback video files recorded, click  to enter the video playback page.




- **Select Video Files**

Select the following options to play video files:

	<p>Select the video file to play on the drop-down menu.</p>
	<p>Search video files by specified date and time.</p>
	<p>Search video files by events.</p>
	<p>Select to play files stored on local PC.</p>
	<p>Select files stored on the disk of VioGate.</p>

- **Save Video Files**

To save a playing file on a particular remote storage device, click . The files can be saved as vg3 format.


- **Play Video Files**

Use the following controls to play the video:



	Play
	Stop
	Fast playing video file
	Play video frame by frame
	Adjust playback screen size
	Take snapshot



#### 4.1.6 Other Function Buttons




#### Function keys of PTZ camera


- i. : Adjust focusing lenses to minimize scope.
- ii. : Adjust focusing lenses to maximize scope.
- iii. Click other buttons to adjust PTZ camera lenses.
- iv. When VioGate uses Merit Lilin and Pelco D protocols, use your mouse to press and hold the button to adjust camera direction of the PTZ camera, you can then move the camera angle continuously. To stop moving the angle, simply release the mouse.

## 4.2 System Configuration

The sections in System Configuration are shown below:




## Icons on System Settings Page



### 4.3 System Settings

Enter the basic information for the system such as the server name, date and time, and verify the current software version.



- **Server Name**

Enter a unique server name for VioGate. The server name can contain up to 20 characters. The name cannot contain the following characters:

**" , ; \ : | \* ? > < ' ` [ ] / %**

- **Description**

Enter a description of VioGate (126 characters at maximum), e.g. the administrator name, department name, or the location of the server.

- **Version**

The firmware version of VioGate will be displayed in this field.

- **Time Zone; Current Date and Time**

Select the time zone according to the location of the server, and adjust the date and time accordingly. If you enter invalid date and time settings, you may encounter the following problems:

- ✓ If you are using web browser to view live video, the time displayed will not be the same as the time shown on the personal computer.
- ✓ Incorrect date and time information will be displayed when you try to play video files or view event logs.



**Note:** Daylight time saving will be automatically adjusted for different time zones.

## 4.4 Network Settings

Select the method VioGate uses to connect to the network. Enable multicast function if necessary. If you are not certain how your server connects to the external network or about TCP/IP settings, contact your network administrator.

**Network Settings**

☐ Obtain IP address settings automatically (DHCP)

☐ Assign IP address settings manually

IP Address: 192 . 168 . 0 . 1

Subnet Mask: 255 . 255 . 255 . 0

Gateway: 192 . 168 . 0 . 1

☒ Use broadband connection to access the Internet (PPPoE)

User Name: viola

Password: \*\*\*\*\*

☒ Try to use DHCP when failed

☒ Enable Dynamic DNS Service DynDNS Link...

User Name: viotest

Password: \*\*\*\*\*

Host Name: viotest@dyndns.org

Note: You should specify the IP address of DNS server when enabling DDNS service.

☒ Dynamic IP Address ☐ Fixed IP Address

☐ Specify DNS Server 0 . 0 . 0 . 0

☐ Enable Multicast Group IP Address: 239 . 255 . 45 . 45 Port: 9000

Back to Live Video Save

- **Obtain IP address settings automatically (DHCP)**

Often used in conjunction with cable modem and corporate networks, the system will obtain IP address and other TCP/IP information automatically. If your network supports Dynamic Host Configuration Protocol (DHCP), VioGate will obtain IP address and other TCP/IP information automatically from the DHCP server.

- **Assign IP address settings manually**

Specify the IP address and other settings if you are using ADSL connection service. If the server's external network uses ADSL service to connect to the Internet, specify a valid IP address provided by the ISP. Enter the following settings:

- IP address
- Subnet Mask
- Gateway

- **Use broadband connection to the Internet (PPPoE)**

PPPoE is often used in dial-up ADSL broadband service. Enter the user name and password provided by the ISP to connect to the Internet.

☒ Try to use DHCP when failed

The server will use DHCP for network connection when PPPoE connection fails.

- **Enable Dynamic DNS service**



**Note:** If you assign IP address settings manually to connect to the Internet, and want to enable dynamic DNS service, specify a DNS server.

To enable external access to VioGate by a domain name, activate dynamic domain name service. Apply for an account and register a dynamic domain name from a dynamic domain name service provider. Please refer to Appendix B for further details. After you have registered a dynamic domain name and completed the setup, VioGate will automatically update the dynamic IP address with the service provider's server.

- **Specify DNS Server**


To assign a specific DNS server, enter the server's IP address.

- **Enable Multicast**

Multicast enables the server to broadcast data to a specified group of clients simultaneously to control network flow.

## 4.5 IP Security

Specify the connections to be allowed and denied to access VioGate. Choose one of the following options to restrict access from a network or an IP address (host) to the server:



- **Allow all connections (default setting)**

Allow connection from all hosts to the server.

- **Allow connections from the following list only**

Allow connection from hosts specified on the list only.



**Note:** When this function is enabled, you can only use PC that the IP address is listed on the connection list to find VioGate by VioGate Finder. The IP address not included in the list will not be able to detect VioGate not listed in allowed connections.

- **Deny connections from the following list**

Deny connection from hosts specified on the list.




**Note:** When setting the connection lists, make sure your PC is included in the list of hosts that connection to the server is allowed. Otherwise when this setting is applied, VioGate will disconnect your PC when you apply the new settings.

## 4.6 User Management

This section enables you to maintain user accounts and configure account privilege for effective management of server access. The server can provide services to any authorized users. The system has a default account that cannot be renamed or deleted. **It is strongly recommended that you change the administrator password the first time you login the server for system security.** The default user name and password are:

User name: <b>administrator</b>
Password: <b>admin</b>



To add a new user, enter the following information.

- **User name**

The user name can contain up to 32 characters. It is case-insensitive, and can contain double-byte characters, e.g. Chinese, Japanese, and Korean, but cannot contain the following ones:


" , ; \ : | \* ? > < ' ` [ ] / %

- **Password**

The password is case-sensitive and can contain up to 16 characters. It is recommended to set a password longer than 6 characters.



- **Advanced User Settings**




The image shows a Windows-style dialog box titled "Advanced User Settings". On the left, there is a "User Name:" label above a text box containing the word "test". Below the text box are two buttons: "Select All" and "Clear All". On the right side of the dialog, there are three grouped sections of checkboxes. The first section, labeled "Monitoring", contains four checkboxes: "Camera-1", "Camera-2", "Camera-3", and "Camera-4", all of which are checked. The second section, labeled "Playback", also contains four checkboxes: "Camera-1", "Camera-2", "Camera-3", and "Camera-4", all of which are checked. The third section, labeled "Other", contains two checkboxes: "Camera PTZ Control" (checked) and "System Administration" (unchecked). At the bottom right of the dialog are "OK" and "Cancel" buttons.

You may configure the following permissions to a user account:

- ✓ **Monitoring**  
Allow users to view live video of assigned cameras.
- ✓ **Playback**  
Allow users to view recorded video of assigned cameras.
- ✓ **Camera PTZ Control**  
If the attached camera supports PTZ functions, users can control Pan/Tilt/Zoom functions of assigned camera.
- ✓ **System Administration**  
The user will have the right to change all system settings.

## 4.7 Camera Settings




Define the following settings for the camera:

i. Camera name

20 English characters or 10 Chinese characters can be used. The name can contain only English alphabets, numbers, dash (-), or Chinese characters (excluding " , ; \ : | \* ? > < ' ` [ ] / % )

ii. Resolution



The higher the resolution, the larger the display of the recording files. If the bit rate is unchanged, image quality will decrease but this will not increase the size of recording files.

NTSC Full D1 (720x480)



NTSC Half D1 (720x240)




NTSC CIF (352x240)



NTSC QCIF (176x112)

### iii. Bit rate


Select the bit rate for camera. Bit rate controls the storage space required by recording files. You can refer to the approximate disk space required every day by each channel for all bit rate options. The total bit rate of the four channels of VioGate will be affected by network bandwidth.



**Note:** MPEG-4 applies dynamic storage technology. Storage capacity varies according to the motion of image recorded by the camera.

### iv. Frame rate

The faster the frame rate, the smoother the display image is displayed. It is recommended to set the frame rate as 15fps for optimized smoothness and quality of the image.



v. Brightness

vi. Contrast

vii. Hue

viii. Saturation

You can adjust the best image for each channel of VioGate-340 when different cameras are implemented. If cameras of relatively less optimized default settings are used, you can adjust the settings here for better image quality.

Brightness:	<input type="text"/>	0
Contrast:	<input type="text"/>	0
Hue:	<input type="text"/>	0
Saturation:	<input type="text"/>	0

- **Pan/ Tilt/ Zoom**

If the camera connected to VioGate supports P/T/Z function, you can operate it with the control unit on the monitoring page.



To use P/T/Z function, configure the following settings:

- ✓ **Camera ID/ Speed**

Select the ID of P/T/Z camera to control and the moving speed of operation. Camera ID can be 255 at maximum. Speed refers to the moving speed of PT control unit. The larger the number, the faster the moving speed. Please refer to the user manual of the camera for further information.

- ✓ **Mode**

If manual mode is selected, the camera will stay still and you can control the angle via the monitoring page. When preset mode is selected, you can select preset points for PTZ camera. PTZ camera will move according to each preset position (1-10) every 10 seconds.

- ✓ **Protocol**

The system supports multiple PTZ protocols: Computar YCH-02, DynaColor, SONY VISCA, Merit Lilin, Panasonic WV-CS564, Honeywell GC-655, Honeywell GC-755, VideoTrec, VideoTrec SP-8006W, and Pelco D-Type.


Pan/Tilt/Zoom:	<input checked="" type="radio"/> Enable <input type="radio"/> Disable			Left	Up	Right	Zoom In	Zoom Out
Camera ID / Speed:	1 <input type="text"/>	2 <input type="text"/>		Down			Focus Far	Focus Near
Mode:	<input type="radio"/> Manual <input checked="" type="radio"/> Preset							
Protocol :	Pelco D-Type							
				1	2	3	4	5
				6	7	8	9	10



**Note:** For further PTZ support information, please refer to Appendix E.

## 4.8 Recording Settings

To save live video and activate video playback function, enable recording function. VioGate supports multiple-interval scheduled recording.




- **Recording Mode**

- ✓ **Continuous Recording**  
VioGate will continuously record video stream to the storage.
- ✓ **Scheduled Recording**  
VioGate will start to record according to specified day, start time and end time. The system also supports overnight scheduled recording. For instance, when you set the start time for recording as 6pm on Monday and the end time as 9am, the system will automatically defines the end time as 9am on the following day, i.e. Tuesday.

- **Storage Settings for Recording/ Snapshot**

Configure the storage settings of VioGate. VioGate provides two disks at maximum as built-in storage. You may also select to use NAS, Windows, or FTP as the storage platform. Firmware version 2.1.0 or later supports second storage for recording when primary storage fails.



The dialog box is titled "Storage Settings for Recording / Snapshot" and contains several sections for configuring storage settings.

**Storage Platform:**

- ☒ Primary Storage
- ☐ Secondary Storage
- ☒ Enable second storage

**Storage Platform Options:**

- ☒ Local
- ☐ NAS
- ☐ Windows
- ☐ FTP

**Storage Access Information:**

IP Address / Host Name:

Port:

Share Folder:

User Name:

Password:

Path for Recorded Video Files:

Path for Snapshot Pictures:

**Disk Full Settings:**

When the available storage space is less than  percent (%)

- ☒ Overwrite the oldest recorded files
- ☐ Stop saving newly recorded files

Switch to another storage space  minutes when original storage space fails.

☒ Use Smart Recording technology for saving storage space.

Buttons: OK, Cancel



## Storage Platform & Storage Access Information

Select one of the following storage types and enter the necessary information.

- ✓ Local Disk  
To use local disk as storage device, please format the disk in **System Tools—Disk Tools** section.
- ✓ NAS  
To use NAS (Network Attached Storage) as external storage device, enter the IP address of NAS, user name and password to access the server.
- ✓ Windows  
If VioGate is set to save files to a share folder on a Windows server, enter the IP address of the server, user name and password to access the server.
- ✓ FTP  
To save files to an FTP server, enter the IP address of the server, user name, and password. If the FTP server uses a particular port, specify the port number.

The screenshot shows a configuration window titled "Storage Platform" and "Storage Access Information". Under "Storage Platform", there are four radio buttons: "Local", "NAS" (which is selected), "Windows", and "FTP". Below this, the "Storage Access Information" section contains several input fields: "IP Address / Host Name" with the value "0.0.0.0", "Port" with a spinner box set to "21", "Share Folder" with the value "dvr", "User Name" (empty), "Password" (empty), "Path for Recorded Video Files" with the value "record", and "Path for Snapshot Pictures" with the value "snapshot".

Storage Platform	
<input type="radio"/> Local	<input checked="" type="radio"/> NAS
<input type="radio"/> Windows	<input type="radio"/> FTP

Storage Access Information	
IP Address / Host Name:	0.0.0.0
Port:	21
Share Folder:	dvr
User Name:	
Password:	
Path for Recorded Video Files:	record
Path for Snapshot Pictures:	snapshot

### Storage Path

Enter two different paths (folders) to store the recorded video files and snapshot pictures.



**Note:**

- i. To save video files via FTP, enter a valid path.
- ii. Both recording and snapshot files are stored in the same path.

### Disk Full Settings

Select an action to be taken when available storage space falls under a specified limit:

- ✓ Overwrite the oldest recorded files
- ✓ Stop saving newly recorded files

Disk Full Settings

When the available storage space is less than  percent (%)

☒ Overwrite the oldest recorded files

☐ Stop saving newly recorded files



**Note:** When saving files on an FTP server, the system will not be able to detect the storage size of the FTP server. Therefore, you will not be able to set the limit for storage space. The system will overwrite old files or stop saving files when there is no available space on the FTP server.

### Switch storage space

Set the number of minutes VioGate should wait to switch to another storage space when the original one fails. Note that you have to enable second storage first before setting this function.

### Smart Recording

Smart Recording is a function to optimize recording quality and recording space of VioGate. When Smart Recording is enabled, VioGate will determine recording performance according to the change of input image. When the screen does not change (nearly still image), VioGate will enter Smart Recording mode after 5 minutes. The frame rate will drop to 1fps and bit rate will drop at the same time. VioGate will determine the frame rate according to the complexity of the monitoring image. When a moving object enters the monitoring area, VioGate will resume from Smart Recording mode and uses previous frame rate and bit rate settings to acquire the best recording quality.



**Note:** Please make sure the camera is installed in an environment where the brightness is higher than the minimum brightness required by the camera to avoid too much noise which may lead to inability to action of Smart Recording function.

Switch to another storage space  minutes when original storage space fails.

☒ Use Smart Recording technology for saving storage space.

## 4.9 Event Handling

When an event occurs, the system will automatically trigger alarms, and be configured to ensure correct capturing and recording of video files. The events are listed below:


- Motion Detection
- Video Input Loss
- Network Failure
- Storage Connection Failure
- Storage Space Full
- Alarm Input 1, 2, 3, 4



## Motion Detection

VioGate provides up to 256 detection areas to replace the monitoring screen of your camera. When motion detection is enabled, any movement detected in the monitoring area will trigger a notification sent by the system. Select area of focus for motion detection. Click **Advanced** under Motion Detection, and select the camera movement and its dissection. Then select the sensitivity of motion detection for the specified area. It is recommended to select higher sensitivity level if the camera is located in indoor environment. If the camera is located in outdoor environment where motion often occurs, it is recommended to select lower sensitivity level for motion detection.

VioGate also supports motion detection for multiple time periods according to your selection.





**Note:** When adjusting the sensitivity level of VioGate, it will affect the sensitivity of Smart Recording. Please make sure the settings are necessary for the operation.

Sensitivity:

Medium
Highest
High
Medium
Low
Lowest

To set motion detection schedule, enable Scheduled Detection and configure the settings.

Detection Mode

☐ Continuous Detection

☒ Scheduled Detection

Settings...

**Motion Detection Schedule**

☐ SUN ☐ MON ☐ TUE ☐ WED ☐ THU ☐ FRI ☐ SAT


Start: PM 02:53 Stop: PM 02:53

Start Date	Hr:Min	End Date	Hr:Min
SUN	03:00	SUN	06:00
SUN	09:00	SUN	12:00
SUN	15:00	SUN	18:00
SUN	21:00	MON	00:00
MON	03:00	MON	06:00
MON	09:00	MON	12:00
MON	15:00	MON	18:00
MON	21:00	TUE	00:00
TUE	03:00	TUE	06:00

Add Date Delete Date OK Cancel

### **Video Input Loss**

You can select different settings of notification when an image is missing from one of the frames. This notification will sound the alarms that you have programmed when image source is missing.



### **Network Failure**

When the Internet access of the video server is disrupted, an alarm will sound. In addition to voice alert when Internet access is disrupted, all other notification will be reactivated when Internet access is restored. This does not include GPIO connection installed on your own.




### **Storage Connection Failure**

When the video server has difficulties in storing files, i.e. the power supply to the main file server is interrupted, a system alarm will sound.



### Storage Space Full

The system will sound when the free space falls below a preset limit. To customize the storage capacity, click **Setting**. Enter the capacity in percentage in the window after the command function. When you have input the capacity, click **OK** and then **Save**.



**Note:** GPIO device supports only 0-24V (voltage). It is recommended to use voltage of less than 24V. For further information, Appendix H GPIO Connections.



## Alarm Input

Select other command input function or make them notification alarms for other actions or function.

<input checked="" type="radio"/> Alarm Input 1	Setting...
<input type="radio"/> Alarm Input 2	Setting...
<input type="radio"/> Alarm Input 3	Setting...
<input type="radio"/> Alarm Input 4	Setting...

**Settings for Alarm Input Event** [X]

Triggering Level

☐ High ☒ Low

OK Cancel



**Note:** If you choose to store the files on an FTP server, the video server will not be able to detect the amount of available space on the FTP server. Therefore, you will not be able to set the percentage for the "Storage Space Full" event.

## 4.10 Event Action Settings

You can perform multiple event actions for a single event, and connect GPIO devices to generate alarms.



- Recording

To activate recording function of particular cameras when an event action is detected, enable Recording function in Event Action and modify the settings. To specify the storage path for recording files, click **Storage Settings**.

Motion Detection - Event Action Settings

☒ Recording [Settings...](#)

**Recording Settings for Event Action**

Camera

☐ Camera-1 ☐ Camera-2

☐ Camera-3 ☐ Camera-4

Recording

Start recording video  second(s) before the event occurs.


Stop recording video  second(s) after the event ends.

Storage Path

☒ Primary Storage  [Storage Settings...](#)

OK Cancel

Select the storage path for recording and enter relevant information.  
Configure disk full settings and relevant action to take, i.e. overwrite the oldest recorded files or stop saving newly recorded files. Note that you can enable second storage and configure the storage settings.



The dialog box is titled "Storage Settings for Recording / Snapshot" and features a blue header bar with a close button (X) in the top right corner. It is divided into several sections:

- Storage Selection:** At the top, there are three radio buttons: "Primary Storage" (selected), "Secondary Storage", and a checkbox "Enable second storage".
- Storage Platform:** Below this, there are four radio buttons: "Local" (selected), "NAS", "Windows", and "FTP".
- Storage Access Information:** This section contains several input fields:
  - "IP Address / Host Name:" with the value "0.0.0.0".
  - "Port:" with a spinner box set to "21".
  - "Share Folder:" with the value "dvr".
  - "User Name:" and "Password:" with empty text boxes.
  - "Path for Recorded Video Files:" with the value "record".
  - "Path for Snapshot Pictures:" with the value "snapshot".
- Disk Full Settings:** This section includes:
  - A label "When the available storage space is less than" followed by a spinner box set to "1" and the text "percent (%)".
  - Two radio buttons: "Overwrite the oldest recorded files" (selected) and "Stop saving newly recorded files".
- Switch to another storage space:** A label followed by a spinner box set to "0" and the text "minutes when original storage space fails."
- Smart Recording:** A checked checkbox labeled "Use Smart Recording technology for saving storage space."


At the bottom of the dialog box are two buttons: "OK" and "Cancel".

When video input loss detection is activated for a channel set for recording, in case that channel, e.g. channel 1, loses video input, the consecutive channel, channel 2, will replace the primary channel for recording.

- Snapshot

To activate snapshot function of particular cameras when an event action is detected, enable Snapshot function in Event Action and modify the settings.


To specify the storage path for snapshot files, click **Storage Settings**.



When video input loss detection is activated for a channel set for snapshot taking, in case that channel, e.g. channel 1, loses video input, the consecutive channel, channel 2, will replace the primary channel for taking snapshot.

- Alert e-mail

Enable this option, enter a valid mail server name, recipient's email address, email subject and other settings. An alert e-mail will be sent to particular recipients when an event action is detected. You can select to attach snapshots of particular cameras in the e-mail. Click **Test** to send an e-mail to test the function.



The dialog box is titled "Alert E-mail Settings for Event Action" with a red close button in the top right corner. It contains several input fields: "Mail Server:", "Recipient(s):", "Subject:", and "Message:". Below the "Recipient(s):" field, there is a note: "(Please split e-mail addresses by ; e.g. John@hotmail.com; Mary@hotmail.com)". At the bottom, there is a section titled "Attach Snapshot" containing four checkboxes: "Camera-1", "Camera-2", "Camera-3", and "Camera-4". At the very bottom of the dialog are three buttons: "Test", "OK", and "Cancel".

When video input loss detection is activated for a channel set for snapshot taking, in case that channel, e.g. channel 1, loses video input, the consecutive channel, channel 2, will replace the primary channel for snapshot taking. That snapshot will be attached to the alert e-mail.




**Important Notice:** If you are using fixed IP address for network connection and enabling dynamic DNS service at the same time, please specify DNS server.

- Alert SMS (Short Message Service)

When an event action is detected, an SMS message will be sent to a particular phone number. You must purchase SMS package from TW SMS

(<http://www.twsms.com/>) or VOLA (<http://www.vola.it/>) to acquire user name and password, and use the points for SMS service. After entering all necessary information, you can send a test message before saving the settings.



The dialog box titled "Alert SMS Settings for Event Action" contains the following fields and controls:


- User Name:** A text input field.
- Password:** A text input field.
- Mobile Phone:** A text input field.
- Message:** A large text area for composing the SMS message.
- Sending Interval:** A label followed by the text "Send an SMS every", a spin box set to "1", and the text "minute(s)".
- SMS Application:** A dropdown menu with "IT VOLA" selected. A list is shown below the dropdown with "TW SMS" highlighted and "IT VOLA" below it.
- Buttons:** "Test", "OK", and "Cancel" buttons are located at the bottom.



**Important Notice:** VioGate must be able to connect to the Internet.

- Alarm buzzer

This is an internal buzzer of the server. Set the alarm, and the buzzer will sound when an event action is detected. To stop the alarm, disable this function.




- Notify remote client

When an event action is detected, a notification icon will pop up on the PC of the users.

- Alarm output 1, 2, 3, 4


You can connect up to four GPIO devices to VioGate for action detection and set the alert.





## 4.11 Statistics and Logs

You can view the record of users currently logged on and previously logged on to the system. In event logs section, you can check all events detected by the system and back up the logs.



- **Active Users**

Display information of all currently active users, i.e. user name, IP address, and login time.


- **Historical Users**

Display information of all users who have logged in VioGate including user name, IP address, and login time.

- **Event Logs**

Display system warning and error messages. You can also back up and clear all event logs in this section.


## 4.12 System Tools



You can use the following system tools to configure VioGate.


- **System Update**

You can download the latest system firmware from QNAP website ([www.qnap.com.tw](http://www.qnap.com.tw)) and update your system. Your system will acquire enhanced functions or higher stability after system update. Please make sure the firmware is correct and read the relevant release notes before update.




- **Backup/ Restore**

You can back up and restore system settings and user information to your computer, and reset the system to default.



- **Restart/ Shut down System**

You can select to restart or shut down VioGate in this section. When VioGate is recording and the built-in disk is used to store recording files, please shut down the server by this setting so that magnetic head of the hard disk will resume to its place to avoid system malfunction due to sudden power suspension. When the option **Shut down System** is selection, please turn off the power of the server after 30 seconds.



- **Hardware**

This option is enabled by default. When it is enabled, you can press the configuration reset switch of the server for a few seconds until you hear an alert sound, the administrator password and network settings will restore to default. After resetting the system, all connections to VioGate will be allowed.




**Note:** If this option is disabled, you will not be able to reset system by pressing the switch.



- **Disk Tools**

In this section, you can select disk mode: single disk or dual disk linear. You can also view current disk status of VioGate and space available, format and check the disk in this section.



**Note:** Dual disk linear can only combines the storage capacity of two disks to lengthen the time for saving recording data but does not provide RAID protection.

## 5. Using VioGate Player/ Finder/ Master Lite





When selecting to record image files by VioGate, VioGate will automatically save video files in vg3 format to a specified storage device. The video files will be named as **yyyy-mm-dd hh-mm-ss.vg3** (i.e. year-month-date hour-minute-second.vg3). You can connect to VioGate and copy the video files to PC, and launch VioGate Player to view the file content.

### 5.1 Using VioGate Player

Launch VioGate CD-ROM in your PC and install VioGate Player. When finished, double click VioGate Player shortcut on desktop to run the program. The following screen will be shown:




#### Playing Video Files

- Click  and  to select and remove the video files on the playlist.
- Use the function buttons on the bottom left corner of the screen to play, pause, and stop video files.
- Click  or  to adjust the size of playback window.
- Move the arrow on the slide bar to adjust video playing.




## 5.2 Using VioGate Finder


1. Launch VioGate Finder. The program will search for all available VioGate servers in the network. To modify the settings of a server, select an item on the list and click **Configure**.



2. Enter the administrator name and password.



3. Enter the information for VioGate and click **OK**.



The VIOCARD-300 Configuration dialog box is shown. It has a title bar with the text "VIOCARD-300 Configuration" and a close button. The dialog is divided into two sections: "System" and "TCP/IP".

**System Section:**


- Name:** A text box containing "TEST-300".
- Date (mm/dd/yyyy):** Three text boxes containing "02", "15", and "2005" separated by slashes.
- Time (hh:mm:ss):** Three text boxes containing "06", "41", and "32" separated by colons.

**TCP/IP Section:**

- Obtain the IP address automatically (DHCP):** A radio button that is not selected.
- Use Fixed IP Address:** A radio button that is selected.
- IP Address:** A text box containing "192 . 168 . 0 . 1".
- Subnet Mask:** A text box containing "255 . 255 . 255 . 0".
- Gateway:** A text box containing "0 . 0 . 0 . 0".

At the bottom of the dialog are two buttons: "OK" and "Cancel".

4. Click **Details** to view the information of VioGate.




The VIOCARD-300 Server Details dialog box is shown. It has a title bar with the text "VIOCARD-300 Server Details" and a close button. The dialog contains a table with two columns: "Status" and "Value".

Status	Value
Server Name	TEST-300
Version	2.0.0 Build 1430
MAC Address	00-30-02-0E-00-21
DHCP	Enabled
IP Address	172.17.26.85
Subnet Mask	255.255.254.0
Gateway	172.17.26.1

At the bottom of the dialog is a button labeled "Close".

5. To launch the searched result again, click **Refresh**.



6. To close the program, click **Exit**.



### 5.3 Using VioGate Master Lite

Software Features:

1. 1/4/9/12/16/20 channel simultaneous display
2. Supports 32-channel display at maximum
3. Supports picture-in-picture and rotational display
4. Free combination of monitoring screen
5. Remote monitoring high speed dome camera
6. Supports reception of alert messages from remote VioGate
7. Various warning modes


Install VioGate Master Lite from VioGate CD-ROM. Double click the VioGate Master Lite shortcut to launch the program.




Enter the user name and password to login VioGate Master Lite.

Default user name: <b>user</b>
Password: <b>user</b>


The first time you use VioGate Master Lite, the program will search for all available VioGate servers on the network. You can also click Add to add VioGate server manually.



Enter the IP address or domain name, port number, user name and password to add the server for VioGate Master monitoring.



You can then use VioGate Master to manage multiple VioGate servers.



## 6. Maintenance

VioGate has been specially designed to run 24 x 7. The server also provides a dedicated power protection system to protect against system crash caused by power outage. Please read this section carefully for information of system maintenance.

### 6.1 Restart/ Shut down VioGate

To shut down or restart VioGate, go to **System Tools** page. Follow the instructions to restart or shut down the system. You can also shut down the system by pressing the power button of the server.



**Note:** When recording is enabled, data will be written to hard disk continuously. Do not shut down power supply directly or it will cause disk damage. Any improper operation of the system will lead to data damage or loss.

**System Tools**

**System Update**

To update the system, please obtain a new image file and click 'Browse...' to specify the file location.

Current system version: **2.0.0 Build 1229**

**Backup / Restore**

- ☒ Back up all configuration settings.  
Note: Please click "Backup/Restore" button and choose a file to save configuration data.
- ☐ Restore all configuration settings to factory default.
- ☐ Restore all configuration settings from the backup image file.  
Note: Please click 'Browse...' to locate the backup image file you want to restore.

**Restart / Shut down System**

## 6.2 Reset Administrator Password & Network Settings

If you forget the administrator password, you will not be able to login VioGate and perform system administration. To reset the administrator password and network configuration of VioGate to default, please do the following:


1. Press the configuration reset button of VioGate for a few seconds until a beep sound is heard. The network configuration will be reset.
2. Connect VioGate via a web browser to configure the settings. Login with the default administrator name and password:


<b>User name: administrator</b> <b>Password: admin</b>
---



**Note:** If the configuration reset button is disabled in **System Tools—Hardware Settings** page, you will not be able to reset administrator password and network configuration by pressing the reset switch.

When allowed connections are set in IP Security and configuration reset switch is disabled, you must remember the allowed IP addresses, user account and password. Otherwise you may not be able to find the correct IP address of VioGate and reset the system. VioGate must be sent to QNAP to reset configuration and all data on the server will be lost.

 **System Tools**



System Update

To update the system, please obtain a new image file and click 'Browse...' to specify the file location.

Current system version: **2.0.0 Build 1229**

Browse...

System Update

Backup / Restore

☒ Back up all configuration settings.  
Note: Please click "Backup/Restore" button and choose a file to save configuration data.

☐ Restore all configuration settings to factory default.

☐ Restore all configuration settings from the backup image file.  
Note: Please click 'Browse...' to locate the backup image file you want to restore.

Browse...

Backup / Restore

Restart / Shut down System

Restart System

Shut down System


Hardware

☒ Enable configuration reset switch

## 6.3 System Update


When you have successfully registered the product, you will receive email notification on firmware update from QNAP. You can update the system and enjoy new functions free.

To update VioGate firmware version, go to **System Tools – System Update** page. Make sure you have obtained the latest firmware version. Browse and select the appropriate image file and upload it to VioGate.



## 6.4 Restore to Factory Default

To restore VioGate to factory default, connect to the server via web browser. Go to **System Tools – Backup/Restore** page and select to restore the system.



## **Appendix A   Terms and Glossary**

### **TCP/IP (Transmission Control Protocol/ Internet Protocol)**

TCP/IP was originally developed by the Defense Department of the States to allow dissimilar computers to talk. Today, this protocol is used as the basis for the Internet. Because it must span such a large distance and cross multiple, smaller networks, TCP/IP is a routable protocol, meaning it can send data through a router on its way to its destination.

### **DHCP (Dynamic Host Configuration Protocol)**

It is a method for assigning a permanent Internet Protocol (IP) addresses or on the fly to individual computers in an organization's network. Usually it is performed by a DHCP server.

### **FTP (File Transfer Protocol)**

This is a method of moving files from system to system using TCP/IP with FTP application.

### **DHCP IP**

A dynamic IP address is assigned to your computer by your ISP's server so that other computer servers can find your computer when you are connected to the Internet. This IP address changes because whenever your computer reconnects to the Internet, a different IP address will be assigned to your machine.

### **Static IP**

It is a fixed IP address assigned to your computer. IP address is a 32-bit digit used to differentiate each single entity on a network. The IP address is divided into 4 groups of eight bits separated by dots, e.g. 192.168.0.1.

### **PPPoE (Point-to-Point Protocol over Ethernet)**

The Point-to-Point Protocol over Ethernet (PPPoE) feature allows a PPP session to be initiated on a simple bridging Ethernet connected to the client. The session is transported over ATM link via encapsulated Ethernet-bridged frames. The session can be terminated at either a local exchange carrier central office or Internet service provider (ISP) point of presence.



**DNS (Domain Name System)**

Domain Name System identifies each computer as a network node on the Internet using an Internet protocol address system to translate from domain name to IP address and vice-versa.

**DDNS (Dynamic Domain Name System)**

Dynamic DNS (DDNS) service enables clients and servers to automatically register themselves in the database without needing administrators to manually define records.

**Multicast**

Multicast is the technique that allows network data from a single source to be simultaneously transmitted to a selected set of destinations (also called a *host group*). A main advantage of multicast is that it saves network bandwidth by sending only one copy of data over the network.

## Appendix B Dynamic Domain Name Registration

VioGate supports DDNS service provided by DynDNS, ODS, DHS, and DyNS. For example, you can go to the web site of DynDNS (<http://www.dyndns.org/>) and register for a dynamic domain name. Configure and activate DDNS service, then the Internet users will be able to access your VioGate via this dynamic domain name. When the ISP assigns a new WAN IP address, VioGate will update the new address to the DynDNS server automatically.

### Registration Procedure


Please follow the steps below to register a dynamic domain name.

**Note:** This guide is for reference only. If there are any changes, please refer to the instructions or documents on the web site.

1. Open the browser and connect to <http://www.dyndns.org/>. Click **Sign Up Now** to begin registration.



2. Check the box "I have read and agree to the Acceptable Use Policy above".

**DynDNS**

User:  Pass:

[Lost Password?](#) - [Sign Up Now](#)

<a href="#">About</a>	<a href="#">Services</a>	<a href="#">Account</a>	<a href="#">Support</a>	<a href="#">News</a>
-----------------------	--------------------------	-------------------------	-------------------------	----------------------

[My Account](#)  
[Create Account](#)  
[Login](#)  
[Lost Password?](#)

**Create Account**

Please complete the form below to create your account. You will receive an e-mail containing instructions to activate your account. If you do not follow these directions within 48 hours, you will need to recreate your account.

**Search DynDNS**

**Acceptable Use Policy**

Policy Last Modified: August 12, 2005

All services provided by Dynamic Network Services, Inc. ("DynDNS") are provided to you (the "Member") under the Terms and Conditions set forth in this Acceptable Use Policy ("AUP") and any other operating rules and policies set forth by DynDNS. The AUP comprises the entire agreement between the Member and DynDNS and supersedes all prior agreements between the parties regarding the subject matter contained herein. BY COMPLETING THE REGISTRATION PROCESS AND CLICKING THE "Accept" BUTTON, YOU ARE INDICATING YOUR AGREEMENT TO BE BOUND BY ALL OF THE TERMS AND CONDITIONS OF THE AUP.

2. DESCRIPTION OF SERVICE

DynDNS is providing the Member with various DNS-based

I have read and agree to the Acceptable Use Policy above: ☒

3. Enter the user name, email address and password to create an account for DDNS service. Please verify your email address to receive the confirmation message from the server. Then click **Create Account** to proceed.

I understand that each Member may have only one (1) free account, and acknowledge that any creation of multiple free accounts will result in the termination of all of my accounts: ☒

---

### **Username**

Username:

Your username will be used to login to your account and make changes.

---

### **E-mail Address**

E-mail Address:  Confirm E-mail Address:

The e-mail address you enter must be valid. Instructions to activate your account will be sent to the e-mail address provided. You must keep this address current. Any accounts with invalid e-mail addresses are subject to removal without warning. We do not sell our account information to anyone. Read more about our [privacy policy](#).

---

### **Password**

Password:  Confirm Password:

The password you enter will be used to access your account. It must be more than 5 characters and cannot be the same as your username. Do not choose a password that is a common word, or can otherwise be easily guessed.

---

### **Mailing Lists**

DynDNS maintains a number of mailing lists designed to keep our users informed about product announcements, client development, our company newsletter, and our system status. Please use the checkboxes below to alter your subscription preference. Your subscription preference may be changed at any time through the [account settings](#) page.

<b>Mailing List</b>	<b>Subscribe</b>
Announce	<input type="checkbox"/>
MailHop	<input type="checkbox"/>
system-status	<input type="checkbox"/>

---

### **Optional Information**

How did you hear about us:  Details:


Providing this information will help us to better understand our customers, and tailor future offerings more accurately to your needs. Thanks for your help!

**Create Account**

---

Copyright © 1999-2006 [Dynamic Network Services, Inc.](#) - [Privacy Policy](#) - [Acceptable Use Policy](#) - [Trademark Notices](#)

4. If the following web page appears on the screen, your account has been successfully created and a confirmation message has been sent to your e-mail address. Please follow the instructions in the e-mail to activate your account within 48 hours.



5. When you have finished the confirmation process, you can apply for your own dynamic domain name.


## Appendix C Connecting VioGate via PC

To access VioGate by a PC, connect the computer to VioGate by a crossover cable. Configure the network settings of your PC and VioGate in the same network domain. To connect VioGate by default IP address, please configure the network settings of your PC as below:


**IP address: 192.168.0.2**  
**Subnet Mask: 255.255.255.0**

Please follow the steps below to access VioGate by a PC. The example is based on Windows XP.


1. Right click "My Network Places" shortcut on the desktop, and choose "Properties". Right click your network device, and choose "Properties".



2. Highlight Internet Protocol (TCP/IP), and click "Properties".



3. Set the IP address and subnet mask as the following:



4. Restart your personal computer. Launch the web browser (Internet Explorer), and enter the IP address of VioGate **192.168.0.1** in the address bar.


Upon successful connection to VioGate, enter the default user name and password to login the administration page:

User name: <b>administrator</b>
Password: <b>admin</b>




## Appendix D Connecting VioGate via RS-422/ 485 Port

To connect the PTZ camera using the RS-422/485 port, you will need a cable to connect the camera to the server, and a D-Type 9-pin connector. The four connectors for data transfer are shown in the picture below.





To make a communication control wire, follow the steps below (\*):


1. Prepare a D-Type 9-pin female header and the wires necessary for RS-485. Cat.5E network cable will be used in this example. Take four wires for data transfer.



2. Weld the wires to D-Type 9-pin female header.




3. Cover the header carefully.




4. VioGate header is finished.



5. Connect TX+ and RX+ with twist pair (\*\*) as data output D+. Connect TX- and RX- as data input D-.



6. Connect D+ and D- to the RS-485 data control input (\*\*\*) of high speed dome camera.



**Note:**

- \* Sony VISCA uses RS-232 port. This control wire is not applicable.
- \*\* For the communication control wires compatible with RS-485, please refer to the recommended wire list in the user manual.
- \*\*\* DynaColor D7720A is used as an example. The RS-485 design varies among different high speed dome providers. Please refer to the relevant user manuals for reference.

**High Speed Dome Recommendation List:**

<b>Protocol Name</b>	<b>Interface</b>	<b>Preset Mode</b>	<b>Manual Focus</b>
DynaColor 7720A	RS-485	×	×
Sony VISCA VI-D30	RS-232	×	×
Merit Lilin	RS-485	○	×
Panasonic WV-CS564	RS-485	○	×
Honeywell GC-755	RS-485	×	×
Honeywell GC-655	RS-485	×	×
Computar YCH-02	RS-485	○	○
VideoTrec	RS-485	○	×
VideoTrec SP-8006W	RS-485	○	×
Pelco D-Type	RS-485/422	○	○

For the most updated information of recommended high speed dome models, please visit [www.qnap.com.tw](http://www.qnap.com.tw).

## Appendix E PTZ Control Information

1. VioGate-340 supports three types of PTZ control service: Manual Mode, Auto Mode and Preset Mode.
2. All PTZ protocols support Manual Mode. You can use PTZ control panel on the bottom left of Monitoring page to control PTZ device of the active channel.
3. If PTZ control mode is set as Auto Mode or Preset Mode, you cannot use PTZ control panel to control PTZ device on the administration page via IE browser.
4. Only one protocol supports Auto Mode, i.e. DynaColor. PTZ device will rotate 360° automatically in this mode.
5. Some protocols support "Preset mode". In this mode, up to 10 preset positions can be stored for camera surveillance. Monitoring screen of the preset positions will be displayed in order. Please refer to the list below for further information:


### Supported PTZ Protocols Information:


Protocol Name	Interface	Baud Rate (bps)	Start Bits	Stop Bits	Data Bits	Parity Check	Manual Focus Support	Auto Mode Support	Preset Mode Support
Computar YCH-02	RS-485	4800	1	1	8	None	Yes	No	Yes
DynaColor D7720A	RS-485	9600	1	1	8	None	No	Yes	No
Honeywell GC-655	RS-485	9600	1	1	8	None	No	No	No
Honeywell GC-755	RS-485	9600	1	1	8	None	No	No	No
Merit Lilin	RS-485	9600	1	1	8	None	Yes	No	Yes
Panasonic WV-CS564	RS-485	9600	1	1	8	None	No	No	Yes
Pelco D-Type	RS-485/ RS-422	2400	1	1	8	None	Yes	No	Yes
Sony VISCA EVI-D30	RS-232	9600	1	1	8	None	No	No	No
VideoTrec	RS-485	9600	1	1	8	None	No	No	Yes
VideoTrec SP-8006W	RS-485	9600	1	1	8	None	No	No	Yes

For the most updated information of supported PTZ protocols, please visit [www.qnap.com.tw](http://www.qnap.com.tw).

## Appendix F VioGate Finder

VioGate Finder is a dedicated program provided by QNAP to help you search for all available VioGate servers in your local network. VioGate Finder shows all available surveillance servers within the local network and displays the basic information such as servers' names, workgroups and IP addresses. You may also set up the server name, date, time, and basic network configuration of the surveillance server via this program. To use VioGate Finder, you can run the program in VioGate CD-ROM.





## **Appendix G Using VioGate with IP Sharing Router**

### **Configuration for the virtual server on an IP sharing router connecting to VioGate: a fixed IP address mapping approach.**

If VioGate is in the same network with an IP sharing router using a fixed IP address, it can be accessed via some assigned ports of the virtual server on the IP sharing router mapping to the given ports on VioGate. Assign two different ports for monitoring live video on VioGate and playing the recorded video files.

In this case, the following settings of the configuration for the virtual server on the IP sharing router should be reset:

- **Monitoring live video**

You can assign any available port on the IP sharing router to map to port 80 on VioGate.

- **Playing recorded video files**

You can assign port 21 only on the IP sharing router to map to port 21 on VioGate.



## Appendix H GPIO Connections

- Connections for Input/ Output devices



GPIO Input/ Output Connectors

### Description of Output Connector (From left to right)

Cm1	Common 1
NC1	Normal Close 1
NO1	Normal Open 1
Cm2	Common 2
NC2	Normal Close 2
NO2	Normal Open 2
Cm3	Common 3
NC3	Normal Close 3
NO3	Normal Open 3
Cm4	Common 4
NC4	Normal Close 4
NO4	Normal Open 4

### Description of Input Connector (From left to right)

In1	Input 1
Gnd	Ground 1
In2	Input 2
Gnd	Ground 2
In3	Input 3
Gnd	Ground 3
In4	Input 4
Gnd	Ground 4

- **Specifications for General Inputs**

The general inputs can take DC voltage from 0~24V. Voltage above 24V is not recommended.

Input	Voltage Range	
5 VDC	Logic 0	0.5V Max
	Logic 1	4.5V Min
12 VDC	Logic 0	0.5V Max
	Logic 1	11V Min

- **Specifications for General Outputs**

**Relay Contact Ratings**

Contact form	1 FORM C (SPDT)
Contact capacity	coil = 0.36W
Resistive load	1A/125 VAC
( $\cos \theta = 1$ )	2A/24 VDC
Inductive load	0.3A/30 VDC
( $\cos \theta = 0.4$ L/R = 7 msec)	
Rated carrying current	2A
Max allowable voltage	AC 120V. DC 60V
Max allowable current	2A
Max allowable power	48W
Contact material	Ag Alloy

**Relay Coil Specifications (At 20 °C)**

Coil Voltage	Normal Voltage (VDC)	Normal Current (mA)	Coil Resistance (ohm $\pm$ 10%)
5V	5V	66.7	75
Power Consumption (W)	Pull-in Voltage (VDC)	Drop-out Voltage (VDC)	Max Allowable Voltage (VDC)
About 0.36W	75% max 3.75V	10% min 0.5V	110% 5.5V

After connecting your external device, you can plug the connector into the GPIO connectors on VioGate.